









## EXTEND MAST AND SECURE & INSTALL ROTOR, ORIENT IT NORTH, INSTALL ROPE ON YARD ARM FOR G5RV

## **INSTALL TNT MAST SAFETY BOLT DEVICE**



























